

TOOLS NEEDED FOR MAINTENANCE/INSTALLATION FOR Customer Order Displays/ Order Confirmation Systems

(note: Everbrite does **not** provide tools on this list)

PRE-INSTALL	
Fish Tape (100ft min)	Torx T15 (for freestanding units as of 3/23, 2012) and T20
	drivers
WD-40 or similar penetrating oil to remove old nuts from	1/2" & 3/8" electric drill
speaker posts etc	
Basic Hand Tools *	10' DB9 Serial Cable (purchase from Everbrite.Part
	#WI0334ORS)
	E CALLS:
Fish Tape (100ft min)	Small jewelers screwdriver
Digital Volt-Ohm Meter	Vacuum Cleaner (optional)
Basic Hand Tools *	1/2" & 3/8" electric drill
Soldering Pencil(s) with a spool of solder	3/8" screw gun
Torx T15 (for freestanding units as of March 23, 2012)& T20 drivers	Blu-mol Drill bits (Home Depot)
Tie-raps wire ties	RS232 Data Breakout Box
Mild All-purpose cleaner i.e. 409 or Fantastic for cleaning the	10' DB9 Serial Cable (purchase from Everbrite. Reference
faces	Part #WI0334ORS)
Caulk Gun (use for Silicone Sealant)	Lubricant (ie:"snot") must be used when pulling Everbrite
	data/Ethernet CAT5 cables. (Do Not use dish soap-could
	remove the printing on the jacket.)
RJ45/CAT5 Cable Tester which detects opens, shorts, miswir	es and cross-connections at a distance (Klein Tools LAN Scout,
Southwire Datacomm Tester or equivalent)	
INSTALLATIONS or R	epairs to Damaged Units:
Hammer Drill	Torx T15 (for monolith units as of 3/23, 2012) and T20
	drivers
1/2" & 3/8" electric drill	Tie-wraps wire ties
Blu-mol Drill bits (Home Depot)	Mild All purpose cleaner i.e. 409 or Fantastic for cleaning
	the faces
3/8" screw gun	Small jewelers screwdriver
Side Grinder or Sawzall	Vacuum Cleaner
Fish Tape (100ft min)	1/2" Red Head anchor bolts
Digital Volt-Ohm meter	WD-40 or similar penetrating oil to remove old nuts from
	speaker posts.
Basic Hand Tools *	RS232 Data Breakout Box
Soldering Pencil(s) with a spool of solder	Lubricant (ie:"snot") must be used when pulling Everbrite
	data/Ethernet CAT5 cables. (Do Not use dish soap-could
	remove the printing on the jacket.)
RJ45/CAT5 Cable Tester which detects opens, shorts, miswires an	nd cross-connections at a distance (Klein Tools LAN Scout,
Southwire Datacomm Tester or equivalent)	
LED Retrofit Installs or LCD Retrofit into FP4	13 not COD ready + normal INSTALLATION tools:
100' extension cord	Side Grinder or Sawzall
1/8" to 1/2" Metal tapping bits	Basic Hand Tools *
Jig Saw w/metal cutting blades	Metal File
	1/2" & 3/8" electric drill
Pasis Hand Tools to have for a	Il types of service or installations

adhesive cable track (optional to contain data cables etc)