

The scoreboard interface is divided into three main sections: a Red team scoreboard on the left, a central control area, and a Yellow team scoreboard on the right.

- Red Team Scoreboard (Left):** A vertical stack of five score buttons labeled +4, +3, +2, +1, and -1. To the right of the +3 button is an "Edit Score" button. To the right of the +2 button is an "Edit Time Out" button, which is connected to a "Time Out -1" button below it.
- Yellow Team Scoreboard (Right):** A vertical stack of five score buttons labeled +4, +3, +2, +1, and -1. To the left of the +3 button is an "Edit Score" button. To the left of the +2 button is an "Edit Time Out" button, which is connected to a "Time Out -1" button below it.
- Central Control Area:**
 - Top row: "Up Down" (blue), "Edit Time" (red), "Reset Time" (blue), "Time of Day" (blue).
 - Second row: "Period +1" (blue), "BALL POSS." (blue with a double-headed arrow).
 - Third row: "CLEAR KEY" (red), "CLEAR POSS." (red).
 - Bottom row: "EDIT KEY" (red), "RESET KEY" (blue), "RESET POSS." (blue), "EDIT POSS." (red).

Whirlyball Scoreboard

This is an identical copy of the Whirlyball Scoreboard interface described above, featuring the same layout of Red and Yellow team scoreboards and central control buttons.

Whirlyball Scoreboard